





FIG. 3













300a


301a











12/30

## START READING EQUIPMENT LIST





FIG. 14 START SETTING WARNING MODE INSTRUCTION-USE MOBILE TELEPHONE **EQUIPMENT** MOBILE TELEPHONE **NETWORK** CONTROL DEVICE √S151 DISPLAY "CURRENTLY PROCESSING" MEMORY CARD EQUIPMENT ID S153 **∑**\$152 READ EQUIPMENT COMMUNICATION NUMBER EQUIPMENT COMMUNICATION NUMBER √S155 **S154** ESTABLISH COMMUNICATION WARNING MODE WARNING MODE SETTING REQUEST SETTING REQUEST **S156 S157** S158 < GENERATE RANDOM NUMBER R S159 \ C=E (K, R) **S161** C K: SHARED **KEY** S162 **S160** R' = D(K, C)**S163 S164** R' R' K: SHARED KEY √S165 **AUTHENTICATION** A21 NO MATCH **FAILURE S167** R : R' INFORMATION DISCONNECT MATCH **S166** INSTRUCTION AUTHENITICATION FAILURE INFORMATION **S168** S169<sup>5</sup> S170 DISPLAY FAILURE OF AUTHENTICATION A23 RETURN RETURN

14/30











FIG. 17












21/30






FIG. 24





FIG. 25
START PROCESSING TO DISABLE VEHICLE OPERATIONS









FIG. 27







29/30

